

TwistoFIX Ø2

Implants

| Length | Part Number |
|--------|-------------|
| 10mm | 955-4500 |
| 11mm | 955-4501 |
| 12mm | 955-4502 |
| 13mm | 955-4503 |
| 14mm | 955-4504 |
| 15mm | 955-4505 |

Instruments

| | | |
|---------------------------|----------|---|
| TwistoFIX clamp | 914-0015 | 1 |
| TwistoFIX screwdriver | 903-0041 | 2 |
| Screw forceps | 914-0001 | 3 |
| Instrument case, complete | 602-3002 | |

Indications

- Foot surgery :
- Weil osteotomy
 - Closing wedge osteotomy

Applications

- Hand surgery
Percutaneous procedures

Small Bone Innovations International

ZA Les Bruyères - BP28


01960 Péronnas, FRANCE

Tel: +33(0) 474 21 58 19

Fax: +33 (0) 474 21 43 12


Mail: info@sbi-intl.com

Web: www.totalsmallbone.com




TwistoFIX

Just **TWIST** and it's **FIXed**




SBi
SMALL BONE INNOVATIONS


SBi
SMALL BONE INNOVATIONS



1)
The metatarsal osteotomy along the XY axis should be as extended as possible. Two cuts are made to remove a sufficient amount of bone, and thus avoid the risk of hyperpressure due to plantar displacement of the metatarsal head.




2)
- The surface F of the clamp (Pn.914-0015) rests on the metatarsal head during recession of the head.
- Moderately tighten the clamp to allow placement of the drill guide C. The length of the screw is read off from the scale of the ratchet mechanism M.
- Insert the selected TwistoFIX screw into the chuck of the drill up to marking R, and tighten until marking R is flush with the top of the drill guide. Break off the shank with a slight twist.




3)
Remove the clamp and complete insertion of the screw using the screwdriver (Pn.903-0041). The screw head must be fully countersunk.




4)
Resect the bone peak.
Reposition the phalanx.




A)
-Perform a V-osteotomy and remove the bone wedge.
-Close the osteotomy ; this produces elevation of the metatarsal head.



B)
- The surface F of the clamp (Pn.914-0015) rests on the metatarsal head during recession of the head.
- Moderately tighten the clamp to allow placement of the drill guide C. The length of the screw is read off from the scale of the ratchet mechanism M.
- Insert the selected TwistoFIX screw into the chuck of the drill up to marking R, and tighten until marking R is flush with the top of the drill guide. Break off the shank with a slight twist



C)
Remove the clamp and complete insertion of the screw using the screwdriver (Pn.903-0041). The screw head must be fully countersunk.



D)
Reposition the phalanx.